### **FALCON ASPHALT REPAIR EQUIPMENT**

# **Technical Specifications For**

# Three (3) Ton Truck Mounted Portable Asphalt Hot Box & Recycler

### 1. General

Item	Item Description	Compliance
A.	<ul> <li>These specifications describe an asphalt recycler &amp; hot box capable of:</li> <li>Heating and re-heating cold patch asphalt</li> <li>Transporting hot mix, keeping it hot all day and holding hot mix asphalt overnight</li> <li>Recycling asphalt chunks and millings</li> </ul>	Yes No
В.	The asphalt recycler & hot box must be an air jacketed hopper with no moving parts	Yes No
C.	Manufacturer or manufacturer's representative must provide a working demonstration of manufacturer's current equipment.	Yes No
D.	Capacity: 3 Truck Mount	Yes No

### 2. Local Service Provider

Item	Item Description		Compliance
	Bidder must include the name of the local service service Service Provider Name	provider responsible for parts and	Yes No
	Contact Name P Mileage from servicing dealer to end customer	none Number	

### 3. Hopper Construction

Item	Item Description	Compliance
A.	<ul> <li>WALLS</li> <li>Hopper is of triple wall construction and has three parallel walls (inner, middle and outer)</li> <li>Hopper floor and all four hopper walls are heated         <ul> <li>a) Hopper is heated by an air-jacket below the hopper floor and between the inner and middle hopper walls</li> </ul> </li> <li>All walls must be of one-piece, seamless steel construction</li> <li>All front and side hopper walls are parallel and angled (inner, middle and outer)</li> <li>The tops of all three steel layers of the front and rear hopper walls are angled to create a 2" slope</li> <li>Complete area between middle and outer walls is filled with 8 lb density, 2" mineral wool insulation</li> <li>Top of hopper walls secured to each other with 10-gauge steel capping channel and side hopper walls secured to each other with 10-gauge steel corner molding, stopping hopper from losing its shape over time</li> <li>Zip screws may not be used in the construction of the hopper</li> </ul>	Yes No
В.	BURNER BOX IS:  Located below the hopper floor  Constructed of 15.3# channel iron with dimensions of 10" high, 51" long and 34" wide  Insulated with 1" ceramic blanket on all four walls and the floor	Yes No

C.	<ul> <li>HOPPER FLOOR:         <ul> <li>Hopper floor is constructed of a single piece of ¼" plate steel that is a minimum of 34" wide and a minimum of 51" long</li> <li>The hopper floor is free of any steel wall or divider that partitions the hopper into compartments</li> </ul> </li> </ul>	Yes No
D.	<ul> <li>A single, diamond shaped 10-gauge steel heat duct is welded from the front-hopper wall to the back-hopper wall</li> <li>Heat duct is continuously welded</li> <li>Heat duct is a minimum of 12" above the hopper floor</li> </ul>	Yes No
E.	<ul> <li>Overall hopper frame length without the hook lift sub frame not to exceed 12 feet</li> <li>Overall hopper frame width not to exceed 83"</li> <li>Overall height is 51" to the to of hopper with doors closed</li> </ul>	Yes No
F.	<ul> <li>BI-FOLD HOPPER TOP LOADING DOORS</li> <li>Bi-fold steel loading doors are framed on square tubing with angle iron reinforced cross members</li> <li>The area inside loading doors is filled with insulation</li> <li>Doors are hinged to the hopper corners with bolt-on, 1 1/4" diameter 4-bolt pillow block bearings</li> <li>Two hydraulic cylinders with 2.5" bore, 1.5 " rod, and a 16" stroke</li> <li>Loading doors are bi-fold with two equal-size sections hinged together the entire length of the door and covered with a neoprene guard.</li> </ul>	Yes No
G.	<ul> <li>HOPPER REAR MATERIAL METERING DOOR</li> <li>Rear hopper wall includes a single, fully insulated, guillotine-style, hydraulic unloading door</li> <li>Unloading door opening dimensions must be a minimum of 16" high and 33" wide</li> <li>One 2.5" bore, 1.5" rod and 16" stroke hydraulic cylinder</li> <li>Hopper floor asphalt guide allows asphalt to flow onto shoveling apron</li> <li>Detachable and fully adjustable shoveling apron attached to rear of unit</li> <li>Without removing the apron, it must be capable of being positioned to dump asphalt without contacting the apron.</li> </ul>	Yes No
H.	<ul> <li>HOPPER HYDRAULIC CONTROLS</li> <li>Lever on curbside spool valve controls movement of loading doors (raise and hold to open, lower and hold to close)</li> <li>Lever on curbside spool valve controls movement of material door (raise and hold to open, lower and hold to close)</li> </ul>	Yes No
I.	<ul> <li>HOPPER WIRING</li> <li>Plug-in connector to be 7-pin flat RV, 7-pin round or 6-pin round</li> <li>All wires shall be THHN, stranded, copper, and color coded and all wiring and enclosures shall be NEMA-3 rated</li> <li>Wiring connections shall be soldered, sealed in shrink-wrap, covered with high temperature corrugated loom and protected by steel conduit</li> <li>All wiring is external to the hopper walls</li> </ul>	Yes No

# 4. Heat System

Item	Item Description	Compliance
A.	BECKET DIESEL BURNER	Yes No
	<ul> <li>Hopper heated by one 105,000 BTU maximum RW Beckett diesel burner</li> </ul>	
	Diesel burner fuel solenoid powered by a 12-volt system	

	<ul> <li>Burner includes a cad cell (eye) to shut down the flow of fuel if the burner flame is not present</li> <li>A pressurized pump controls the flow of fuel to the diesel burner</li> <li>Diesel burner spark ignition system is powered by a 12-volt battery</li> <li>Burner has automatic recycle on spark system and automatic shutdown safety system</li> <li>Burner has inspection guard that is removable without the use of tools, while standing on the ground</li> <li>Nozzle shall be .75 GPH</li> <li>Diesel burner is engineered to continuously operate while the equipment is in tow and while the hopper is raised</li> </ul>	
В.	<ul> <li>DUAL BURNER HEATING PACKAGE</li> <li>An additional diamond-shaped heat duct is welded inside the hopper from one side hopper wall to the other such that it intersects the front to back heat duct and forms one criss-crossing heat duct</li> <li>An additional 90,000 BTU maximum RW Beckett diesel burner bolts to a second combustion chamber that bolts to the front hopper wall and directs heat into the criss-crossing ductwork inside the hopper</li> <li>Additional combustion chamber is constructed of a one-piece, seamless, vacuum formed ceramic fiber that is 1" thick with an insulation rating for temperatures in excess of 2,000 degrees Fahrenheit</li> <li>An additional 550 CCA 12-volt deep cell battery is mounted in a battery box on the trailer</li> <li>Both hopper diesel burners are controlled by the same digital temperature controller and wall-mounted thermocouple</li> </ul>	Yes No
C.	BURNER COMBUSTION CHAMBER     Constructed of a one-piece, seamless, vacuum formed ceramic fiber that is 1" thick with an insulation rating for temperatures in excess of 2,000 degrees Fahrenheit causing a complete blending of fuel and air	Yes No
D.	BATTERY     Two 550 CCA 12-volt deep cell batteries mounted in battery boxes on the trailer	Yes No
E.	<ul> <li>BATTERY CHARGER</li> <li>A 12-volt marine grade battery charger is mounted on the trailer frame</li> <li>The battery charger is hard wired to the unit's battery</li> </ul>	Yes No
F.	DIESEL EXHAUST     All exhaust produced by the diesel burner vents through a single chimney on the top of the front hopper wall	Yes No
G.	<ul> <li>DIESEL FUEL SYSTEM</li> <li>Trailer has an in-line quick disconnect diesel fuel filter with a water separator, preventing burner failure</li> <li>Hopper Diesel Burner Fuel         <ul> <li>a) Diesel fuel tank has a capacity enough for holding hot mix and heating cold mix for three 8-hour shifts</li> </ul> </li> <li>Fuel tank neck is welded into the fuel tank</li> <li>Fuel tank includes lockable fuel cap</li> </ul>	Yes No
H.	VOLTAGE INDICATOR AND PROTECTION SYSTEM  • Heating system must include a voltage indicator and protector controller to automatically prevent burner from operating below burner manufacturer's required voltage	Yes No
I.	<ul> <li>CONTROLS</li> <li>Digital temperature controller mounted in NEMA-3 rated lockable electrical enclosure</li> </ul>	Yes No

		<ul> <li>Temperature controller is adjustable up to 300 degrees Fahrenheit</li> <li>Burner stops running when the temperature setting on the digital controller is reached.</li> <li>Controller re-fires the burner when the hopper temperature falls 10 degrees below the temperature set by the operator on the controller</li> <li>Burner turns on/off with individual toggle switches (Toggle switches are labeled)</li> </ul>	
•	J.	24-HOUR TIMER     A 24-hour timer is installed on the hopper that can be programmed to start the hopper burner(s) at a pre-set time	Yes No

# 5. <u>Paint</u>

Item	Item Description	Compliance
A.	Manufacturers standard paint color	Yes No
В.	Two coats of epoxy primer and two coats of urethane finish are applied to all parts and entire unit	Yes No
C.	Entire unit, including all bolt-on parts, are blasted prior to painting	Yes No
D.	All accessory bolt-on parts are painted prior to assembly to chassis	Yes No
E.	Non-steel parts are not painted. These components/parts are installed after the paint process is complete	Yes No

# 6. Warranty and Delivery

Item	Item Description	Compliance
A.	Two-year warranty (Pass through warranties will not be accepted)	Yes No
В.	Guaranteed five-year maintenance free combustion chamber	Yes No
C.	Four-hour safety, operation and recycling instruction by a factory-trained technician required upon unit's delivery	Yes No
D.	One Operator / Parts / Service Manual is included upon delivery and available on manufacturers website	Yes No